

## Lighting installation and maintenance

AYRA



### ! WARNING

- Please cut off the power supply during installation or maintenance
- Improper installation of the lamp may cause the lamp to fall, please follow the instructions
- Do not touch the light source when the lamp is working
- Do not replace any cracked protective cover

## I Install

### Pre-installation preparation

- Before installation, be sure to cut off the power supply to prevent electric shock.
  - Please determine the installation according to the installation dimensions in Figure 1 2.
  - Confirm the strength of the screw hanging part to ensure that it can bear the weight of the lamp.
- ※ If the strength is not enough, it is easy to cause accidents such as lamp falling.



### Install the lamp body

- ※ Due to the weight of the lamp, it is recommended that two people install it
- Use the M5\*40 screws provided to pass through the mounting bracket and fix it in the expansion tube on the wall, and fixed lighting fixtures, as shown in Figure 1
  - Use the hanging screw to install the lamp (the hanging screw is purchased separately by the customer, specification M5)  
One person holds the lamp with both hands, and another person puts the washer and nut on the hanging screw, then passes the hanging screw through the mounting hole of the mounting bracket, and fixes the lamp with the washer and nut, as shown in Figure 2 on the right  
After fixing the lamp with the hanging screw, the exposed part of the screw should not be too long to avoid interference when installing the lamp
- ※ Tighten the nut with a wrench to avoid accidents such as the lamp falling due to improper installation.
- ※ Please make sure the lamp is level during installation.

### Connect the power cord

- To ensure safety, be sure to connect the ground wire before connecting the external power cord.
- Align the external power cord with the L, N, and ground wire of the lamp input wire. Do not connect them wrongly.
- After connecting the external power cord and the lamp input wire, take insulation measures to avoid accidents such as electric shock and fire.



### Lighting maintenance

- In order to use this product safely and efficiently, please clean and inspect it regularly (once every 6 months). If you do not inspect it, long-term use may cause accidents such as fire, electric shock, and lamp falling.
- When the lamp needs to be cleaned, please use a soft cloth to sprinkle neutral detergent and wring it out, then wipe it with a dry cloth.  
Do not use detergents other than neutral detergents or organic solvents to wipe the lamp to avoid problems such as discoloration, deterioration, reduced strength or damage to the lamp.
- Please do not spray insecticide on the lamp, otherwise it will cause discoloration or damage to the lamp.